

Wennington Road, Southport PR9 7TN. England Tel: 01704 518000 Fax: 01704 518001 WEB SITE http://www.dorman.co.uk E MAIL address - info@dorman.co.uk

Health and safety

Every effort has been made to ensure the accuracy of the information given in our publications, but in accordance with our policy of continually improving our products we reserve the right to modify designs and specifications whenever necessary. All equipment is designed to conform to relevant British and International standards. Every care is taken to ensure that, as far as reasonably practical, it will perform without risk to health. It is essential that accepted codes of professional practice are followed in the assembly, installation and commissioning of the equipment. If in doubt with respect to any of these instructions, please consult Dorman before installing the device.

Dorman reserves the right to vary any component part to meet the required specifications without prior notice.



Dorman ref. No C64.64172

London Underground Safety Board Instructions

To be read before commencing Operation UNIPART DORMAN



Possession Limit Board



Position unit onto track.




Twist cam to lock.




Unit installed.



Install padlock if required.



Pull release catch to remove.



Use key to switch on/off.



Unscrew bolt using key.



Withdraw bolt.



Use bolt to withdraw battery box.



Withdraw battery box.



Remove plug.



Open box to change batteries

Specification

- Light source high intensity flashing LED's both sides.
- Voltage 6v : Current 48mA
- Low battery warning indicator separate LED behind lens goes steady when batteries need changing.
- Supplied with tough polycarbonate integral rail clamp for easy and quick installation.
- All stainless steel metal fixings.
- Dorman Part No PLB6N/AA/02/001
- Customers Cat Ref 0050/558874
- Replacement battery box DBB6V
- Replacement Air Alkaline batteries B13.12170

Disposal Instructions - In accordance with local and national regulations.