

Wennington Road, Southport PR9 7TN. England Tel: 01704 518000 Fax: 01704 518001 WEB SITE http://www.unipartdorman.co.uk E MAIL address – dorman.info@unipartdorman.co.uk

#### Health and safety

Every effort has been made to ensure the accuracy of the information given in our publications, but in accordance with our policy of continually improving our products we reserve the right to modify designs and specifications whenever necessary. All equipment is designed to conform to relevant British and International standards. Every care is taken to ensure that, as far as reasonably practical, it will perform without risk to health. It is essential that accepted codes of professional practice are followed in the assembly, installation and commissioning of the equipment. If in doubt with respect to any of these instructions, please consult Dorman before installing the device.

Dorman reserves the right to vary any component part to meet the required specifications without prior notice.



Dorman ref. No C64.64173

## LED Points Indicator Extended Visor Installation Instructions

# To be read before commencing Installation





General.

In general, before commencing any modifications, all local safety requirements affecting the safe working environment of the installation either directly or indirectly should be carried out.

The signal should only be modified both electrically and mechanically, by a qualified person. Any modifications should be carried out in a clean & dry environment as possible.

#### **Retro Fitting The MSL Extended Visor**

The Fitting kit supplied should be used to ensure that the Extended Visors are fitted correctly.


Note: Fitting kit contains material for one visor only.


### Unipart Rail - Dorman Part Numbers in Kit of Parts (D84.80139):

B18.18049	.M8x20 Grub screw	(2 off)
B18.17201	.M8 S/S Nut	(2 off)
B20.20222	.Extended Visor	(1 off)
B18.17076	.M5 x 20 Socket Head Screw	(2 off)
B18.17060	.M5 Spring Washer	(2 off)
B18.17022	.M5 Plain Washer	(2 off)
	.M5 S/S Nut	
	Instruction Leaflet	


#### **Retro Fit Operation Procedure Stages:**`
















Using the pre drilled holes as a guide, drill a 5.2mm hole to each side through both existing visors



**Dorman Part Number:** 

PAD's Number: 

