



Wennington Road, Southport PR9 7TN. England  
Tel: 01704 518000 Fax: 01704 518001  
WEB SITE <http://www.unipartdorman.co.uk>  
E MAIL address – [dorman.info@unipartdorman.co.uk](mailto:dorman.info@unipartdorman.co.uk)

#### Health and safety

Every effort has been made to ensure the accuracy of the information given in our publications, but in accordance with our policy of continually improving our products we reserve the right to modify designs and specifications whenever necessary. All equipment is designed to conform to relevant British and International standards. Every care is taken to ensure that, as far as reasonably practical, it will perform without risk to health. It is essential that accepted codes of professional practice are followed in the assembly, installation and commissioning of the equipment. If in doubt with respect to any of these instructions, please consult Unipart Dorman before installing the device. Unipart Dorman reserves the right to vary any component part to meet the required specifications without prior notice.



Certificate No. FM 14371

Dorman ref No.C64.63173 Iss 6  
ECN1328\_0

---


## LED Fixed Tail / Marker Lamp

---

Installation Instructions  
BMAC Single Enclosure

To be read before commencing  
installation.





## **INSTALLATION INSTRUCTIONS**

It is recommended that this unit is installed by a qualified electrician and wired in accordance with the relevant track and signal code of practice.

Please Note: - There are no serviceable parts inside.

1. Undo the door clamp screw, open door and remove the existing tungsten lamp.
2. Remove the existing lens and its fixings.
3. Clean the internal surfaces of the door and remove any sealant from around the lens aperture.
4. Offer the LED Fixed Tail / Marker Lamp into the enclosure and connect the moulded plug into the bayonet lamp holder.
5. Fit the Tail / Marker Lamp into the enclosure, centrally, ensuring it is correctly orientated. (**'TOP'** marked on lens to be uppermost)
6. Close the door, ensuring the Tail / Marker Lamp is located centrally and fully tighten door clamp screw.

## **Specification**

<b><u>Dorman Part Number</u></b>	<b><u>Description</u></b>
LFT2N/R/01/A/00	110V LED Fixed Tail Lamp for BMAC Single Enclosure.
LFT2N/R/02/A/00	24V LED Fixed Tail Lamp for BMAC Single Enclosure.
LFT2N/R/03/A/00	74V LED Fixed Tail Lamp for BMAC Single Enclosure.
LFM2N/W/01/A/00	110V LED Fixed Marker Lamp for BMAC Single Enclosure.
LFM2N/W/02/A/00	24V LED Fixed Marker Lamp for BMAC Single Enclosure.
LFM2N/W/03/A/00	74V LED Fixed Marker lamp for BMAC Single Enclosure.



### **Disposal Instructions:-**

Disposal in accordance with local and national regulations.