



Wennington Road, Southport PR9 7TN. England
Tel: 01704 518000 Fax: 01704 518001
WEB SITE <http://www.unipartdorman.co.uk>
E MAIL address – dorman.info@unipartdorman.co.uk

Health and safety

Every effort has been made to ensure the accuracy of the information given in our publications, but in accordance with our policy of continually improving our products we reserve the right to modify designs and specifications whenever necessary. All equipment is designed to conform to relevant British and International standards. Every care is taken to ensure that, as far as reasonably practical, it will perform without risk to health. It is essential that accepted codes of professional practice are followed in the assembly, installation and commissioning of the equipment. If in doubt with respect to any of these instructions, please consult Dorman before installing the device.

Dorman reserves the right to vary any component part to meet the required specifications without prior notice.



Certificate No. FM 14371

Dorman ref. No C64.65043 Iss 5

MK3 Tail Light Instruction Sheet - Flash

Installation Instructions

To be read before commencing
Operation





Operating instructions

- Rotate the switch at the rear of the lamp to "ON".
- The Lamp illuminates.
- Side indicator lamps illuminate which indicate that the batteries will operate for a minimum of 12 hours.

Low Battery Indication

If the battery voltage falls below the pre-set limit:

- The lamp will remain on automatically (regardless of ON/OFF switch position).
- The side indicator lights will extinguish.
- The batteries should be changed immediately. Only use AIR ALKALINE batteries as replacements. See replacement parts for order code.

Battery Replacement


To replace the batteries, first remove the retaining bolt from the rear of unit through the access hole in the clamp (if fitted). Tools required – 4mm A/F allen key.



Remove the battery carrier. Release the batteries from their location ledge. Visually inspect the battery contact strips, clean the battery contact strips if necessary. Install two new batteries and replace the battery carrier. Secure with the bolt previously removed. There are no serviceable parts in the lamp to keep maintenance to an absolute minimum

Cleaning

The front lens, reflective panel and the side indicators should be kept clean by wiping with soapy water regularly.



Specification

Flash Rate:-	2Hz
On Time:-	25mS
Light output:-	GM/RT 2131 Issue 1
Light colour:-	BS 1376:1974 Signal Red Class B & C
Switch type:-	Optical
Nominal supply voltage:-	6V DC
Nominal current drawn (flashing):-	0.015 amps
Nominal current drawn (steady):-	0.07 amps
Ingress Protection:	IP65

MK3 Tail Lamp

Description

MK3 Tail Lamp – Engraved
MK3 Tail Lamp – Not Engraved

Unipart Dorman Pt No

AUSRTL3/R/E
AUSRTL3/R

Replacement Parts.

Description

AIR ALKALINE BATTERIES DAAB 50
Battery carrier bolt
Battery Carrier
Reflective label

Unipart Dorman Pt No

B13.12170
B17.16146
B05.04018
Contact Unipart Dorman for part No.